




## Adjustment facilities

Convenient height and side adjustment, tilt and front gap adjustment when installed



- 1 Front gap adjustment 0-3 mm
- 2 Height adjustment 0-3 mm
- 3 Side adjustment ± 1 mm
- 4 Tilt adjustment 0–3 mm





## Installation and removal of the drawer

